



Sharp Aquos LC13B2UA Back Case Replacement

Replacing the back casing panel.

Written By: Robert Hobson





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Stand



- Place the TV face down on a flat smooth surface as to not scratch the screen.
- Remove the four 8mm screws attaching the stand to the TV.

Step 2




- Lift the stand off the television.

Step 3 — Back Case



- Remove the two back panels to display the audio and video inputs..

Step 4



- Remove the eight 6mm Phillips screws around the edge.
- Remove the two 6mm Phillips near the inputs.

Step 5



- Lift and remove the back case of the television.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 07:17:24 PM.